

# SIA Sim Docs-Turtle Beach Yoke-Settings

## Turtle Beach Yoke-Reset Settings

**Issue:** When flying a plane in the sim if the user pushes the yoke in the plane climbs and stalls

**To resolve:** Reset the Turtle Beach Yoke to original SIASim settings (not factory default)

Only perform these steps if a student changed the yoke's display setting.

We recommend putting a cover of some sort over the yoke's display to prevent sim users from changing the settings here in the future.

1. Find the display located in the center of the yoke
2. Turn on the sim but do not login
3. After the yoke display boots up:(If the yoke display does not turn on, try logging in and then making the changes)
4. Press the Down Arrow Key on the Yoke Display
5. Select "01. INPUT MODE" (Press the Checkbox button on the Yoke Display to select)
6. Select the "PC LEGACY 2" option
7. Wait for the yoke to reboot
8. Select the "02. PROFILE" Option
9. Select the "SINGLE-ENG. PROP" Option
10. Reboot the SIASim and test
11. Place tape over the Yoke Buttons to prevent users from accidentally making changes to the yoke settings

Last updated:October 3, 2024

